


Installation Manual

HONDA CR-V 5DR
HON-CRV-5-X



COMPONENTS INCLUDED



CL-M02 x 4



CL-P02 x 6



CL-M01 x 2





CL-W01 x 1



Installation



HONDA CR-V 5DR

HON-CRV-5-X



Installation

HONDA CR-V 5DR
HON-CRV-5-X



Installation

HONDA CR-V 5DR
HON-CRV-5-X



Installation

HONDA CR-V 5DR
HON-CRV-5-X

